

# Microwave Dielectric Sensing of Moisture Content in Shelled Peanuts Independent of Bulk Density and with Temperature Compensation

Samir Trabelsi and Stuart O. Nelson  
U. S. Department of Agriculture, ARS  
Athens, Georgia, USA



# Importance of moisture content

- Determines time for harvest
- Determines suitability for storage
- Factor in conditioning for processing
- Factor in price determination

# Moisture in granular materials

- Water is an important component in many organic and inorganic materials.
- There is often a need for on-line sensors for real-time determination of moisture content in granular and powdered materials.
- Industries, for example, include food and agriculture, pharmaceutical, mining, and construction.

# Dielectric properties

- Relative complex permittivity,

$$\varepsilon = \varepsilon' - j \varepsilon''$$

$\varepsilon'$  is the dielectric constant

$\varepsilon''$  is the dielectric loss factor

- Loss tangent,  $\tan \delta = \varepsilon'' / \varepsilon'$
- Dielectric properties are dependent on frequency, temperature, moisture content, and bulk density.

# RF moisture meters

- Most operate at 1- to 20-MHz with parallel-plate or coaxial sample holders
- Influence of ionic conduction
- Readings must be corrected for temperature and bulk density variations
- Separate calibrations required for each kind of grain
- Bulk density fluctuations troublesome for on-line sensing in moving grain

# Microwave moisture sensing

- Meters operate at a few GHz
- No ionic conduction influence
- Bulk density and moisture content can be determined simultaneously from same set of microwave measurements
- Moisture content can be determined independent of bulk density: density-independent calibration functions

# Free-space transmission technique

- Nondestructive and no contact with sample necessary
- Minimal sample preparation required
- Measurement of attenuation and phase shift
- Information relative to entire interacting volume
- Principle can be easily implemented in on-line sensing applications, hand-held and laboratory devices.

$\longleftrightarrow d \longleftrightarrow$

$\varepsilon', \varepsilon''$

$E_i$



$$\Gamma = E_r / E_i$$

$E_r$



$E_t$



$$\tau = \frac{E_t}{E_i}$$

$(M, T, \rho)$



$$\Gamma = \frac{1 - \sqrt{\epsilon}}{1 + \sqrt{\epsilon}} \quad \tau = e^{-j \frac{\omega}{c} \sqrt{\epsilon \mu} d}$$

$$S_{21} = \frac{(1 - \Gamma^2) \tau}{1 - \Gamma^2 \tau^2}$$

$$A = 20 \log |S_{21}|$$

$$\phi = \text{Arg}(S_{21}) - 2n\pi$$

$$\alpha = A/d, \quad \beta = \phi/d + \beta_0, \quad \beta_0 = 2\pi / \lambda_0$$

$$\varepsilon' = \left( \frac{\beta}{\beta_0} \right)^2 \quad \varepsilon'' = \frac{2\alpha\beta}{\beta_0^2}$$

$$\varepsilon' = \left[ 1 - \frac{(\varphi - 360n) \frac{c}{f}}{360d} \right]^2$$

$$\varepsilon'' = \frac{-20 \log |S_{21}| \frac{c}{f}}{8.686\pi d} \sqrt{\varepsilon'}$$



# Shelled peanut samples

- Runner type peanuts, cv. Georgia green
- Bulk density: 0.63 g/cm<sup>3</sup> – 0.69 g/cm<sup>3</sup>
- Moisture content: 4.9% – 25.6% w.b.
- Temperature: 1 °C – 38 °C
- Microwave measurements at 10 GHz

# Density-independent functions

- Jacobsen et al., 1980

$$\psi_1 = \frac{A}{\phi}$$

- Meyer and Schilz, 1981


$$\psi_2 = \frac{\varepsilon''}{\varepsilon' - 1}$$

# Density-independent functions (cont'd)

- Trabelsi et al. 1997


$$\psi_3 = \sqrt{\frac{\varepsilon''}{\varepsilon' (a_f \varepsilon' - \varepsilon'' )}}$$

Where  $a_f$  is the slope in the complex plane representation  $\varepsilon''/\rho$  vs.  $\varepsilon'/\rho$







F=10 GHz



F=10 GHz



# F=10 GHz



# Moisture content determination

- Correlation between  $\psi_i$ ,  $M$ , and  $T$ :

$$\psi_i = a_i M + b_i T + c_i \quad i = 1..3$$

- Moisture calibration equation:

$$M = \frac{\psi_i - b_i T - c_i}{a_i} \quad i = 1..3$$

# Results


Calibration Function	$a_i$	$b_i$	$c_i$	$r^2$	SEC, %
$\psi_1$	0.0033	0.0002	-0.0086	0.97	0.8
$\psi_2$	0.0253	0.0013	-0.0911	0.98	0.6
$\psi_3$	0.0220	0.0014	0.0268	0.98	0.7


# Conclusions

- Three density-independent functions were used to determine moisture content in shelled peanuts
- Moisture calibration equations with temperature compensation were provided
- SEC less than 1% moisture content with better results for  $\psi_2$  and  $\psi_3$

# LABORATORY


## SENSOR PROTOTYPE







# Sensor prototype




At a given frequency:  $ka_f = \text{constant}$

$$\psi^2 = \frac{\varepsilon''}{\varepsilon'(a_f \varepsilon' - \varepsilon'')}$$

$$\psi = \sqrt{\frac{\varepsilon''}{\varepsilon'(a_f \varepsilon' - \varepsilon'')}}}$$

# Free-Space Transmission Technique

- Measurement of attenuation and phase shift
- Minimal sample preparation required
- No contact with sample necessary
- Principle can be easily implemented for on-line sensing



# Relative complex permittivity

$$\varepsilon = \varepsilon' - j\varepsilon''$$

$$\tan \delta = \frac{\varepsilon''}{\varepsilon'}$$

$\varepsilon'$  is the dielectric constant

$\varepsilon''$  is the dielectric loss factor

